
-500 SERIES-



MORE THAN LOGIC. UNITING ART + ENGINEERING.







email: info@meris.us phone: 747.233.1440 website: www.meris.us

TABLE OF CONTENTS

SECTION 1 PG. 1 FRONT PANEL CONTROLS

SECTION 2 PG. 2 SIGNAL FLOW OVERVIEW

SECTION 3 PG. 3-4 CONTROLS IN DEPTH

3a - KEYS AND SCALES

3b - PITCH CORRECTION AND GLIDE CONTROL

3c - TIME DIVISION CONTROLS


SECTION 4 PG. 5 TRIGGERING PITCH VALUES WITH A MIDI KEYBOARD

SECTION 5 PG. 5 TEMPO

SECTION 6 PG. 5 FACTORY RESET

SECTION 7 PG. 5 TECHNICAL SPECIFICATIONS

SECTION 1 - FRONT PANEL CONTROLS




SECTION 2 - SIGNAL FLOW OVERVIEW

The Hedra features 2 distinct delay line configurations:


1. Pitch Feedback On (button is lit):

In this mode, Hedra is configured to have one delay line (520 msec) with three inputs and one output. In this mode, the repeats are recycled through the pitch shifters




2. Pitch Feedback Off (button is unlit):

In this mode, Hedra is configured to have one delay line (520 msec) with three inputs and one output. In this mode, the repeats are mixed in after the pitch shifting.



SECTION 3A - KEYS AND SCALES

Along with the front panel Key selection available on Hedra, hold the alt button and turn the Key knob to modulate through and select among the following scales:



Major: Semi-tones: 2 - 2 - 1 - 2 - 2 - 2 - 1

Intervals: Root, Major 2nd, Major 3rd, Perfect 4th, Perfect 5th, Major 6th, Major 7th, Octave

Minor: Semi-tones: 2 - 1 - 2 - 2 - 1 - 2 - 2

Intervals: Root, Major 2nd, Minor 3rd, Perfect 4th, Perfect 5th, Minor 6th, Minor 7th, Octave

Melodic Minor: Semi-tones: 2 - 1 - 2 - 2 - 2 - 2 - 1

Intervals: Root, Major 2nd, Mlnor 3rd, Perfect 4th, Perfect 5th, Major 6th, Major 7th, Octave

Notes: When you ascend the melodic minor scale you use the above intervals, but depending on the composition, when you descend you might want to use the intervals of the minor scale. Use an expression pedal with Hedra to choose how the scale reacts to your playing.

Harmonic Minor: Semi-tones: 2 - 1 - 2 - 2 - 1 - 3 - 1

Intervals: Root, Major 2nd, Minor 3rd, Perfect 4th, Perfect 5th, Minor 6th, Major 7th, Octave

Double Harmonic: Semi-tones: 1 - 3 - 1 - 2 - 1 - 3 - 1

Intervals: Root, Minor 2nd, Major 3rd, Perfect 4th, Perfect 5th, Minor 6th, Major 7th, Octave

Lydian Pentatonic: Semi-tones: 4 - 2 - 1 - 4 - 1


Intervals: Root, Major 3rd, Tritone, Perfect 5th, Major 7th, Octave

Notes: This scale was inspired by the incredible music and playing of Marty Friedman and Jason Becker. One of the modes of the Hirajoshi scale, Raga Amritavarshini, Malashri, Shilangi, and Batti Lydian.

Minor Pentatonic: Semi-tones: 3 - 2 - 2 - 3 - 2


Intervals: Root, Minor 3rd, Perfect 4th, Perfect 5th, Minor 7th, Octave

SECTION 3B - PITCH CORRECTION AND GLIDE CONTROL



Hedra features 3 different pitch corrections settings or a pitch glide amount as listed in the knob graphic below. When Loose Correction is selected, the notes are forced into the current Key and Scale but pitch bending is not removed from the input. When Strict Correction is selected, the notes are forced into the current Key and Scale but pitch bending is removed from the input.

SECTION 3C - TIME DIVISION CONTROLS



The Alt control under each Pitch knob is a corresponding Time Division. The Time Division Knobs sets the delay of each pitch shifted voice by a fraction of the overall delay time set by the Tap Tempo switch. Ex: a dotted eighth note is ¾ of a beat.

SECTION 4 - TRIGGERING PITCH VALUES WITH A MIDI KEYBOARD

Using our MIDI I/O. Hedra accepts MIDI Note On and Off messages to hard tune the pitch shift voices to the exact notes you play. Sending a single Note On Message into the Hedra will just tune the Pitch 1 value. sending two Note On Messages will tune Pitch 1 and Pitch 2, and (as expected) sending three Note On Messages will tune all three pitch values. When Note Off messages are received, the corresponding pitch value will mute. Here are a couple of creative possibilities that open up when connecting a keyboard: turn Time Divisions to zero and the MIX Knob to max and the keyboard will turn your input audio into a whole new playable instrument, use a DAW or MIDI Sequencer to play a 3 part song along with your dry signal, or turn the delay and feedback to max and use a MIDI keyboard to build sonic sculptures one note at a time.

SECTION 5 - TEMPO

In Hedra you can set the tempo using one of the following tapping in quarter notes using the integrated Tap switch, MIDI Beat Clock, or Tempo MIDI CC. (An updated manual including MIDI information will be provided soon.)

SECTION 6 - FACTORY RESET

Holding down the "Bypass Switch" button (or R Top LED button) on power up resets all of the presets and all of the global settings back to their original factory values. Once the reset is complete, simply recycle the power on the unit.

SECTION 7 - TECHNICAL SPECIFICATIONS

Conversion 24 bit A/D and D/A DSP 32 bit floating point

Sample Rate 48000 Hz

SNR -116 dB Signal to Noise Ratio (typical)

Frequency Response 20Hz-20kHz

Bypass 100% Analog Bypass

Linking Stereo and surround linkable

1/0 Burr-Brown precision balanced input and output drivers

FC Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] this device may not cause harmful interference, and [2] this device must accept any interference received, including interference that may cause undesired operation.

This equipment requires shielded interface cables in order to meet FCC class B limit.

Any unauthorized changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.