



Sadowsky Onboard Electronics with Vintage Tone Control

Compatibility:

This wiring schematic applies to the following Sadowsky MetroLine and MasterBuilt bass models:

- 21-Fret M-Style Bass

The controls are: Volume, VTC, Treble and Bass. Push/Pull on VTC knob for preamp bypass.

VTC stands for Vintage Tone Control (pull up on the knob for total bypass).

Installation requires a side jack and a battery compartment. If not already done, we recommend shielding the control cavity and pickup cavities at the time of installation. We highly recommend installation by a professional guitar technician or luthier if routing and drilling is required for a battery compartment and/or side jack.

This system is not compatible with EMG or any other active pickups requiring anything other than a 250K or 500K volume pot. For these applications, please custom order a parts-only preamp kit and use your original volume pot.

The M-Style pickup should be wired to the 3-way switch as: Series / Parallel / Single Coil.

NOTE: For more information visit our website or contact us on info@sadowskybass.de