

# STANDARD INSTALLATION

After you have removed the original RIC saddle assembly with the three mounting screws, follow the diagram below to install your Full Contact RIC Bridge, steps 1-4.

