

## HOW DOES IT WORK?

**Volume** - Controls the output volume.

**Gain** - Controls the amount of distortion in the circuit, turn it to the left to clean up your tone.

**Treble** - Boosts and cuts at approximately 10kHz.

**Bass** - Boosts and cuts at approximately 90Hz.

**Middle** - Boosts and cuts the frequencies selected by the Mid Range switch.

**Mid Range** - Up sets the Middle knob to affect approximately 1kHz. Down affects approximately 360Hz.

**Pickups** - Changes the input impedance to best accept either passive or active pickups.

## POWER REQUIREMENTS

**9V Center Negative** - Using anything else will ruin your pedal and void the warranty. Consumes 16mA.

## WARRANTY

All Westminster Effects carry a limited lifetime warranty for pedals sold within the United States and a one-year warranty for pedals sold internationally, for workmanship and components. The warranty does not cover misuse or damage due to accidents. Tampering with components such as trimpots voids the warranty.