



TRS-MIDI TYPE A (MIDI STANDARD)



- MIDI 5 (Sink) - TRS Tip
- MIDI 4 (Source) - TRS Ring
- MIDI 2 (Shield) - TRS Sleeve
- MIDI 1 - not connected
- MIDI 3 - not connected

TRS-MIDI TYPE B



- MIDI 5 (Sink) - TRS Ring
- MIDI 4 (Source) - TRS Tip
- MIDI 2 (Shield) - TRS Sleeve
- MIDI 1 - not connected
- MIDI 3 - not connected