



TREMBLE

T-M-14
tremolo

Owner`s Manual

All of the TONE CITY products were Poured into our enthusiasm and focus. We never stop on the path of development.

CONTROLS

VOL - Controls the output volume.

DEPTH - Controls the intensity of tremolo.

SPEED - Control the speed of tremolo. Colckwise is speed up, left is slow down.

JACKS

INPUT - 1/4" jack on the input side.

OUTPUT - 1/4" jack on the output side.

SWITCH

FOOT SWITCH - turn on/off the pedal.

POWER

This pedal should be operate at 9V DC Negative Center .
If the use of other specifications of the power supply
cause damage. Your warranty will be voided.