

BLUES MAN

T-M-17 overdrive

Owner's Manual

All of the TONE CITY products were Poured into our enthusiasm and focus. We never stop on the path of development.

CONTROLS

SWITCH

VOL - Controls the output volume.

GAIN - Controls the amount of gain.

TONE - Make the tone of pedal brightens or darkens. Colckwise is brighter, anticlockwise is darker.

FOOT SWITCH - turn on/off the pedal.



JACKS

INPUT - 1/4" jack on the input side.

OUPUT - 1/4" jack on the output side.

This pedal should be operate at 9V DC Negative Center. If the use of other specifications of the power supply cause damage. Your warranty will be voided.