

## COMP ENGINE

T-M-13 compressor

Owner's Manual

All of the TONE CITY products were Poured into our enthusiasm and focus. We never stop on the path of development.

## CONTROLS

**VOL** - Controls the output volume.

**COMP** - Controls compression ratio.

**ATTACK -** Controls the position of the voice head when compression begins.

## JACKS

**INPUT -** 1/4" jack on the input side. **OUPUT -** 1/4" jack on the output side.

## SWITCH

FOOT SWITCH - turn on/off the pedal.



This pedal should be operate at 9V DC Negative Center . If the use of other specifications of the power supply cause damage . Your warranty will be voided.