



T - M - 12phase

Owner's Manual


All of the TONE CITY products were Poured into our enthusiasm and focus. We never stop on the path of development.

**FEEDBACK** - Controls the intensity of feedback signal.

**DEPTH** - Controls the depth of phase.

**RATE** - Controls the speed of phase.Colckwise is speed up, left is slow down.

FOOT SWITCH - turn on/off the pedal.



**INPUT -** 1/4" jack on the input side.

**OUPUT -** 1/4" jack on the output side.

This pedal should be operate at 9V DC Negative Center. If the use of other specifications of the power supply cause damage. Your warranty will be voided.