

HOW DOES IT WORK? Right side - Edwards Left side - 1689

Volume - Controls the output volume.

Gain - Controls the amount of gain in the circuit.

Tone - A typical tone control. Straight up is flat. To the left darkens your tone, and to the right brightens it.

Presence (Edwards) - A presence cut control that allows you to dial in the high end. To the left is brighter; to the right is darker.

Clean (1689) - Dial in how much of your clean tone comes through. Acts as a cut, so all the way left has more cleans while right cuts them.

Clip - Two-way switch on the left and three-way on the right for different voicings.

POWER REQUIREMENTS

9V Center Negative - Using anything else will ruin your pedal and void the warranty. Consumes 94mA.

WARRANTY

All Westminster Effects carry a limited lifetime warranty for pedals sold within the United States and a one-year warranty for pedals sold internationally, for workmanship and components. The warranty does not cover misuse or damage due to accidents. Tampering with components such as trim pots voids the warranty.