## MODE SELECT

RATE: -----Controls BATE in all modes

DEPTH:

Controls DEPTH in all modes



## **EFFECT TYPE:**

Tri Chorus, Rotary, Flanger

### **Power Requirement:** 9VDC Center Negative, 65mA+

Power Supply Required.

# Input/Output:

Mono Instrument In, Mono Instrument Output



### TEXTURE:

TRI CHORUS MODE: Controls LEO Shape from Sine to Triangle to Square **ROTARY MODE: Controls Simulated** Distance from Cabinet, Left for further, roomier sounds, right for close, more Tremolo style sounds

**ROTO FLANGE MODE: Turning right** introduces Positive feedback

### LEVEL:

Controls Output Level

