

Source Audio Nemesis Delay

Quick Start Blueprint

PEDAL IN (TRS): Tap Tempo & Expression Pedal Connection

USB: Connect a USB mini-B cable to use the Neuro App or Desktop Editor.

TIME: Sets the delay time.

FEEDBACK: Controls the number of repeats. Use caution with high feedback!

OUTPUT 1 (Mono)

OUTPUT 2 (Stereo)

MOD: Sets the depth of the delay modulation

MIDI 5-pin DIN Output

RATE: Sets the speed of the delay modulation

ON/OFF Footswitch: Engage or disengage the delay effect.

POWER: 9VDC only. Center negative. 200mA. Preferably Isolated. PSU included.

Control Input (TRRS): Connect to external Source Audio utility devices.

MIX: Sets the wet/dry mix of the delay effect. Noon is 50/50.

INTENSITY: Functions vary per engine.

INPUT 1 (Mono)


INPUT 2 (Stereo)

Beat Division Switch: Set your beat division for tapping in a tempo.

MIDI 5-pin DIN Input

PRESETS: Press + hold to save a preset. Push to cycle through preset slots.

TAP Footswitch: Tap in your tempo. Hold to freeze the delay tail. Hold bypassed to cycle presets.



INTENSITY KNOB



TRAILS MODE: Press+hold Control Input, then press ON/OFF Footswitch to toggle on/off.

INFINITE HOLD/FREEZE: Press+hold TAP footswitch while playing for infinite repeats.

LEARN MORE

USER MANUAL



[sourceaudio.net/
user-manuals](https://sourceaudio.net/user-manuals)

PRODUCT PAGE



[sourceaudio.net/
nemesis-delay-adt](https://sourceaudio.net/nemesis-delay-adt)

BLOG



[sourceaudio.net/
blog](https://sourceaudio.net/blog)

VIDEOS



[sourceaudio.net/
videos](https://sourceaudio.net/videos)

SOURCE AUDIO
STORE



[sourceaudio.net/
store](https://sourceaudio.net/store)

NEURO &
DOWNLOADS



[sourceaudio.net/
editorsandfirmware](https://sourceaudio.net/editorsandfirmware)